

Step1 - identify in what state is your iPhone 3G and activate it if necessary

IPHONE 3G IS NOT ACTIVE

This means that your iPhone 3G was purchased but never used with a valid SIM card. We will define this condition as INACTIVE.

IPHONE 3G IS ACTIVE

This means that your iPhone 3G was used with a valid SIM and was synchronised at least once with your PC/MAC. We will define this condition as ACTIVE.

To find out if your iPhone 3G is ACTIVE or INACTIVE switch on your iPhone 3G and observe the screen:

If you see the iTunes logo along with a USB cable, and a slide button showing "Slide for emergency". If you slide the bar, a keypad appears.

Your iPhone 3G is INACTIVE. You will have to activate it before you can unlock it.

To activate your iPhone 3G go to <http://www.iclarified.com/entry/index.php?enid=1573> and follow the instructions provided on that web site.

Once you have followed this procedure, your iPhone menu will appear which means your iPhone is now active. Proceed to Step 2.

If you see the Springboard with lots of icons like SMS, Calendar etc. .

Your iPhone 3G is ACTIVE.
You are lucky!! Unlocking your iPhone is very simple now. Proceed to Step 2.

Step2 - unlock your iPhone 3G

You will need:

1. An ACTIVE iPhone 3G (you need to have completed Step 1)
2. **Simlibre** - Buy one from us (www.simlibre.com)
3. A network SIM card which you want to use on your iPhone 3G. Make sure the SIM card you want to use is active.

Take your iPhone 3G, enable Airplane mode and disable 3G and put the Simlibre along with this SIM card in your iPhone 3G, following the instructions given in the animation on our home page www.simlibre.com.

Wait a few seconds, and disable Airplane mode to get network on phone.

Your phone should get network. If it doesn't get network, please try to switch off your iPhone for 5 minutes and retry the whole process.

Now you can use your iPhone 3G as it has been unlocked. You can use EDGE, GPRS and all functions of iPhone 3G.

3G service depends on the type of SIM card you have and it also depends on the availability of 3G network in your area. In all those countries where there is no 3G, users are advised to switch off 3G mode.